


## How to import the RS232 Projector Display Database into the Synergy software.

Go to the “Synergy” page or the “Software Configuration page” on the iKON AVS web site

On the Synergy page select the “Downloads” tab


Click on the “Synergy RS232 Projector Database.IXL” link save this file onto your computer.

Open the Synergy Editor Software.

Click on the “Edit RS232 Displays” button 


A window will open called “RS232 display selector”



Within this window click on the Import button 

A window will open where you can search your computer for the saved “Synergy RS232 Projector Database.IXL”



Navigate to the saved “Synergy RS232 Projector Database.IXL” and click on the open button 

The RS232 Projector Database will now be imported for use into the Synergy software