

PNP8 PodNet Messages

The PNP8 is pre-configured with fixed PodNet messages.

The PNP-8 sends out a fixed PodNet message as the button is pressed it only sends once on each operation.
The messages are:-

	PODNET MESSAGE No.
PUSH BUTTON 1	25
PUSH BUTTON 2	26
PUSH BUTTON 3	27
PUSH BUTTON 4	28
PUSH BUTTON 5	29
PUSH BUTTON 6	30
PUSH BUTTON 7	31
PUSH BUTTON 8	32

The PNP-8 receives fixed PodNet messages to light the led's within the push buttons. The button operation occurs as long as the message is 'high' and ceases when the message goes 'lo'.

	PODNET MESSAGE No.
LED 1 ON	1
LED 2 ON	2
LED 3 ON	3
LED 4 ON	4
LED 5 ON	5
LED 6 ON	6
LED 7 ON	7
LED 8 ON	8

	PODNET MESSAGE No.
SLOW FLASH LED 1	9
SLOW FLASH LED 2	10
SLOW FLASH LED 3	11
SLOW FLASH LED 4	12
SLOW FLASH LED 5	13
SLOW FLASH LED 6	14
SLOW FLASH LED 7	15
SLOW FLASH LED 8	16

	PODNET MESSAGE No.
FAST FLASH LED 1	17
FAST FLASH LED 2	18
FAST FLASH LED 3	19
FAST FLASH LED 4	20
FAST FLASH LED 5	21
FAST FLASH LED 6	22
FAST FLASH LED 7	23
FAST FLASH LED 8	24