

Connecting the SPC-PP1 RELAY PACK

Installation

The SPC-PP1 is designed to be surface mounted on a flat surface. After removing the cover it will be seen that there are four easily accessible mounting holes.

Mechanical installation and connection of the SPC-PP1 should be carried out before any Mains power is applied. The SPC-PP1 should not be used in areas of extreme heat or moisture.

Local Connections

Detachable screw terminals are used to connect directly to the SPC, Synergy Controllers screen relays connections, these provide the power and the control signals to the Relays in the SPC-PP1.

Testing of these connections is recommended before connecting the Mains and screen and can be done by operating the SPC Controller and observing the raise and lower LED'S for correct operation.

Both the Mains and Screen power connections should be made using suitable mains cable with the correct rating and carried out by a suitably qualified engineer.

