

## How to update the SPC editor software for use with an AU4


Go to the “AU4” page” on the iKON AVS web site

On the “AU4” page select the “Downloads” tab


Click on the “SPC Editor Update” link and save this file onto your computer

Locate the saved “IkonProjectorPanelEditor.exe” on your computer

Right click on the saved “IkonProjectorPanelEditor.exe” file and select cut

On your computer select the Start button  and go to “Computer”

In the new window go to search at the top right



In the search box type “Spall”

Double click and open on the found folder called “Ikon Spall”

Within this opened folder, right click and select paste

A window will open called “Move File”

Select the “Move and Replace” option

You have now updated the SPC Editor software

Please close all opened windows, and open the SPC Editor Software

Please ensure that the software is now “Ikon SPC Editor 1.2.3”

You will now be able to program you SPC program into the AU4

This will allow the SPC to control the AU4 and select the inputs and operate the volume